



**OPEN** Industry Standard, Flexible Architecture

**GREEN** Less Heat, Less Power Consumption

**STABLE** Robust Design, Quality Parts

Stable and  
Reliable Solution

**Server/Workstation**

Motherboard

**6U8X-EGS2 H100**

**6U8X-EGS2 H200**

**User Manual**

English



Version 2.12

Published Dec. 2025

Copyright©2025 ASRock Rack Inc. All rights reserved.

## Copyright Notice:

No part of this documentation may be reproduced, transcribed, transmitted, or translated in any language, in any form or by any means, except duplication of documentation by the purchaser for backup purpose, without written consent of ASRock Rack Inc.

Products and corporate names appearing in this documentation may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners' benefit, without intent to infringe.

## Disclaimer:

Specifications and information contained in this documentation are furnished for informational use only and subject to change without notice, and should not be constructed as a commitment by ASRock Rack. ASRock Rack assumes no responsibility for any errors or omissions that may appear in this documentation.

With respect to the contents of this documentation, ASRock Rack does not provide warranty of any kind, either expressed or implied, including but not limited to the implied warranties or conditions of merchantability or fitness for a particular purpose.

In no event shall ASRock Rack, its directors, officers, employees, or agents be liable for any indirect, special, incidental, or consequential damages (including damages for loss of profits, loss of business, loss of data, interruption of business and the like), even if ASRock Rack has been advised of the possibility of such damages arising from any defect or error in the documentation or product.



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

## CALIFORNIA, USA ONLY

The Lithium battery adopted on this server motherboard contains Perchlorate, a toxic substance controlled in Perchlorate Best Management Practices (BMP) regulations passed by the California Legislature. When you discard the Lithium battery in California, USA, please follow the related regulations in advance.

“Perchlorate Material-special handling may apply, see [www.dtsc.ca.gov/hazardouswaste/perchlorate](http://www.dtsc.ca.gov/hazardouswaste/perchlorate)”

### Setting up the Server in a Restricted Access Location/Restricted Access Area

- Access can only be gained by service persons or by users who have been instructed about the reasons for the restrictions applied to the location and about any precautions that shall be taken.
- Access is through the use of a tool or lock and key, or other means of security, and is controlled by the authority responsible for the location.
- Leave enough clearance (25 inches in the front and 30 inches in the back of the rack) to allow the front door to be opened completely and to allow for sufficient airflow.
- This product is for installation merely in a Restricted Access Location.
- This product is not suitable for use with visual display work place devices according to §2 of the the German Ordinance for Work with Visual Display Units.
- Only skilled person and Instructed person can remove the chassis covers to access the inside of the system.

**ASRock Rack’s Website: [www.ASRockRack.com](http://www.ASRockRack.com)**

## Replaceable Batteries


### CAUTION

**RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.  
DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS**

### Warning

When removal of the chassis lid required for servicing:

- Turn off power and unplug any power cords/cables, and
- Reinstall the chassis lid before restoring power.



## Important Safety Instructions

Pay close attention to the following safety instructions before performing any of the operation. Basic safety precautions should be followed to protect yourself from harm and the product from damage:

- Operation of the product should be carried out by suitably trained, qualified, and certified personnel only to avoid risk of injury from electrical shock or energy hazard.
- Disconnect the power cord from the wall outlet when installing or removing main system components, such as the server motherboard and power supply unit.
- Place the system on a stable and flat surface.
- Use extreme caution when working with high-voltage components.
- When handling parts, use a grounded wrist strap designed to prevent static discharge.
- Keep the area around the system clean and clutter-free.
- Keep all components and printed circuit boards (PCBs) in their antistatic bags when not in use.
- Handle a board by its edges only; do not touch its components, peripheral chips, memory modules or contacts.
- The power cord must be connected to a socket or outlet with a ground connection.

## Contents

<b>Chapter 1 Introduction</b>	<b>1</b>
1.1 Shipping Box Contents	2
1.2 Specifications	3
<b>Chapter 2 Server System Overview</b>	<b>6</b>
2.1 System Components	6
2.2 Internal Features	7
2.3 System Front Panel	9
2.4 System Rear Panel	10
2.5 I/O Panel	11
2.6 LED	16
<b>Chapter 3 Hardware Installation and Maintenance</b>	<b>19</b>
3.1 Server Top Cover	20
3.2 Hard Drive	24
3.3 Power Supply	26
3.4 System Fan	28
3.5 Add-in Card	30
3.6 GPU Tray	39
<b>Chapter 4 Server Motherboard (SP2C741D32G-2L+)</b>	<b>40</b>
4.1 Layout	40
4.2 Block Diagram	44
4.3 Installing the CPU and Heatsink (LGA 4677 Socket)	45
4.4 Installing the Memory Modules (DIMM)	52
<b>Appendix</b>	<b>53</b>
Installing the Server in a Rack	53

# Chapter 1 Introduction

Thank you for purchasing 6U8X-EGS2 H100 or 6U8X-EGS2 H200, a reliable barebone system produced under ASRock Rack's consistently stringent quality control. It delivers excellent performance with robust design conforming to ASRock Rack's commitment to quality and endurance.

This guide provides the instructions of insertion and extraction of chassis components, such as chassis covers, system fans, power supplies, hard drive trays, and other main components this system supports. If the system is pre-installed a server motherboard, refer to the server motherboard user manual for the information of the server motherboard components, specifications and BIOS settings.

System	ASRock Rack Server Motherboard
6U8X-EGS2 H100	SP2C741D32G-2L+
6U8X-EGS2 H200	SP2C741D32G-2L+



*Because the hardware specifications might be updated, the content of this documentation will be subject to change without notice.*



*The illustrations shown in this manual are for reference purposes only and may not exactly match the model purchased.*



*If requiring technical support related to this system, please visit the website for specific information about the using model.*  
<http://www.asrockrack.com/support/>

## 1.1 Shipping Box Contents

Item	Quantity
Server Barebone: 6U8X-EGS2 H100 or 6U8X-EGS2 H200	1
CPU Heatsink	2
Rail Kit	1
Accessory Box - 8 Power Cords - 1 Quick Installation Guide - 2 Screws for M.2 Sockets - 4 CPU Non-fabric Carriers (2 E1A, 2 E1B)	1



*If any items are missing or appear damaged, contact the authorized dealer.*

## 1.2 Specifications

6U8X-EGS2 H100, 6U8X-EGS2 H200	
System	
Form Factor	6U Rackmount
Dimension	930 x 448 x 264.7mm (36.6" x 17.6" x 10.4")
Support MB	SP2C741D32G-2L+
Front Panel	
Button	Power button w/ LED, reset button, NMI button, UID button w/ LED
LED	System fault LED, hard drive activity LED
I/O Port	2 RJ45 (1GbE) by Intel® i350, share with rear I/O 1 Dedicated IPMI, shares with rear I/O 4 Type-A (USB3.2 Gen1) 1 DB15 (VGA)
External Drive Bay / Storage	
Front Side Drive Bay	8 Hot-swap 2.5" NVMe (PCIe5.0 x4) drive bays 4 Hot-swap 2.5" NVMe (PCIe5.0 x4)/SATA drive bays
Internal Side	1 M-key (PCIe3.0 x4 or SATA 6Gb/s), supports 2280/22110 form factor [PCH] 1 M-key (PCIe3.0 x4), supports 2280/22110 form factor [PCH]
Power Supply	
Type	4+4 CRPS
Output Watt	3002.4W @ 220-240Vac input 2900W @ 200-220Vac input
Efficiency	80-PLUS Titanium
AC Input	200-240Vrms, 50/60Hz
System Fan	
Fan	21 PWM 80x80mm fans

Processor System	
GPU	<p><b>6U8X-EGS2 H100:</b> NVIDIA® HGX H100 8-GPU with NVIDIA® NVSwitch™</p> <p><b>6U8X-EGS2 H200:</b> NVIDIA® HGX H200 8-GPU with NVIDIA® NVSwitch™</p>
CPU	Supports 5th and 4th Gen Intel® Xeon® scalable processors
Socket	Dual Socket E (LGA 4677)
Thermal Design Power	Up to 350W
Chipset	C741
System Memory	
Supported DIMM Quantity	16+16 DIMM slots (2DPC)
Supported Type	Supports DDR5 288-pin RDIMM, RDIMM-3DS
Max. Capacity per DIMM	RDIMM: 96GB RDIMM-3DS: 2H- 128GB / 4H- 256GB
Max. DIMM Frequency	5600MT/s (1DPC)* / 4400MT/s (2DPC)* on 5th Gen Intel® Xeon® scalable processors 4800MT/s (1DPC)* / 4400MT/s (2DPC)* on 4th Gen Intel® Xeon® scalable processors  *Memory speed and capacity support vary by CPU SKU.
Voltage	1.1V
PCIe Expansion Slot	
PCIe x16	<p><b>Rear:</b> 8 HHHH PCIe5.0 x16 5 FHHL PCIe5.0 x16</p>
Ethernet	
Additional GbE Controller	Intel® i350: 2 RJ45 (1GbE)
Server Management	
BMC Controller	ASPEED AST2600
IPMI Dedicated GLAN	1 Realtek RTL8211F for dedicated management GLAN

Graphics	
Controller	ASPEED AST2600
VRAM	DDR4 512MB
Rear I/O	
Button	Power button w/ LED, reset button, NMI button, UID button w/ LED
LED	System fault LED, hard drive activity LED
Video Port	1 DB15 (VGA)
USB3.2 Gen1 Port	2 Type-A (USB3.2 Gen1)
RJ45	2 RJ45 (1GbE) by Intel® i350, share with front panel 1 Dedicated IPMI, shares with front panel
System BIOS	
BIOS Type	AMI UEFI BIOS; 256Mb (32MB) SPI Flash ROM
BIOS Feature	ASRock Rack Instant Flash, ACPI 6.4 and above compliance wake up events, SMBIOS 3.5.0 and above, Plug and Play (PnP)
Hardware Monitor	
Temperature	CPU, MB, card side temperature sensing
Fan	Fan tachometer CPU quiet fan (allows chassis fan speed auto-adjust by CPU temperature) Fan multi-speed control
Voltage	P0_VDDCR_CPU0, P0_VDDCR_CPU1, P0_VDDCR_SOC, P0_VDD_18_DUAL, P0_VDD_11_S3, P0_VDDIO, P1_VDDCR_CPU0, P1_VDDCR_CPU1, P1_VDDCR_SOC, P1_VDD_18_DUAL, P1_VDD_11_S3, P1_VDDIO, +BAT, +12V, +3VSB, +5VSB
Environment	
Temperature	Operation temperature: 10°C ~ 35°C Non operation temperature: -40°C ~ 70°C
Humidity	Non operation humidity: 20% ~ 90% (non condensing)




*The functions are supported depending on the type of the server motherboard. Refer to the server motherboard manual for more information.*


# Chapter 2 Server System Overview

This chapter provides diagrams showing the location of important components of the server system.

## 2.1 System Components




## 2.2 Internal Features




No.	Description
1	<p><b>Top:</b> 4+4 CRPS</p> <p><b>Bottom:</b> 8 HHHL PCIe5.0 x16 slots</p>
2	<p><b>Top:</b> 5 FHHL PCIe5.0 x16 slots Rear I/O panel</p> <p><b>Bottom:</b> 6 PWM 80x80mm rear fans</p>
3	Fan board (FB)
4	5 PWM 80x80mm top fans ( <b>left-to-right:</b> FAN11 ~ FAN15)
5	Server motherboard (MB)
6	Backplane board (BPB)
7	<p><b>Top:</b> 8 Hot-swap 2.5" NVMe (PCIe5.0 x4) drive bays [PCIe switch] 4 Hot-swap 2.5" NVMe (PCIe5.0 x4) [CPU1]/SATA [PCH] drive bays Front I/O panel (<i>depends on the specification of the server motherboard</i>)</p> <p><b>Bottom:</b> 10 PWM 80x80mm front fans</p>

## 2.3 System Front Panel



No.	Description
1	8 Hot-swap 2.5" NVMe (PCIe5.0 x4) drive bays [PCIe switch] <b>Top:</b> NVME2, NVME4, NVME6, NVME8 <b>Bottom:</b> NVME1, NVME3, NVME5, NVME7
2	4 Hot-swap 2.5" NVMe (PCIe5.0 x4) [CPU1]/SATA [PCH] drive bays <b>Top:</b> NVME10/SATA2, NVME12/SATA4 <b>Bottom:</b> NVME9/SATA1, NVME11/SATA3
3	Front I/O panel <i>(depends on the specification of the server motherboard)</i>
4	10 PWM 80x80mm front fans <b>Top:</b> FAN6 ~ FAN10 <b>Bottom:</b> FAN1 ~ FAN5


## 2.4 System Rear Panel



No.	Description
1	4 Power supply units ( <b>top-to-bottom</b> : PSU_L1 ~ PSU_L4)
2	Rear I/O panel
3	2 FHHL PCIe5.0 x16 slots ( <b>top-to-bottom</b> : Riser_L1, Riser_L2)
4	3 FHHL PCIe5.0 x16 slots ( <b>top-to-bottom</b> : Riser_R1, Riser_R2, Riser_R4)
5	4 Power supply units ( <b>top-to-bottom</b> : PSU_R1 ~ PSU_R4)
6	4 HHHL PCIe5.0 x16 slots (PCIE8 ~ PCIE5)
7	6 PWM 80x80mm rear fans <b>Top</b> : FAN21 ~ FAN19 <b>Bottom</b> : FAN18 ~ FAN16
8	4 HHHL PCIe5.0 x16 slots (PCIE4 ~ PCIE1)


## 2.5 I/O Panel

### Front I/O Panel



No.	Description
1	2 Type-A (USB3.2 Gen1) ports (USB3_1_2)
2	2 Type-A (USB3.2 Gen1) ports (USB3_3_4)
3	1 DB15 (VGA) port
4	1 UID button w/ LED
5	1 Power button w/ LED
6	1 Reset button
7	1 NMI button
8	<b>Top:</b> 1 Hard drive activity LED <b>Bottom:</b> 1 System fault LED
9	1 Dedicated IPMI LAN port
10	1 RJ45 (1GbE) LAN port (LAN1)
11	1 RJ45 (1GbE) LAN port (LAN2)

## Rear I/O Panel



No.	Description
1	2 RJ45 (1GbE) LAN ports (LAN1, LAN2)
2	1 DB15 (VGA) port
3	1 Dedicated IPMI LAN port
4	2 Type-A (USB3.2 Gen1) ports
5	1 UID button w/ LED
6	1 Power button w/ LED
7	1 Reset button
8	1 NMI button
9	1 Hard drive activity LED
10	1 System fault LED

### UID Button

Press the UID button to toggle the front and rear UID LEDs on and off. Use this button to locate the server working on behind a rack of servers.



*Press and hold the UID button for 4 seconds, the BMC will trigger an external reset.*

## Power Button

Press the power switch button to toggle the system power on and standby/sleep modes. To remove all power from the system completely, disconnect the power cord from the server.

## Reset Button

When the system is completely unresponsive, press the system reset button to reboot the server without shutting it off and initialize the system.

## NMI (Nonmaskable Interrupt) Button

Press the NMI button with a paper clip or pin to generate a nonmaskable interrupt and to put the server in a halt state for examination.

## Status LED Definitions


UID LED	
Status	Description
Off	System identification is disabled.
Blue	System identification is active.

Power LED	
Status	Description
Off	Power off
Green	Power on


Hard Drive Activity LED	
Status	Description
Off	Hard drive inactive
Green	Hard drive active

System Fault LED	
Status	Description
Off	Normal
Red	System fault

## Front Dedicated IPMI LAN Port




## Rear Dedicated IPMI LAN Port



Activity/Link LED	
Status	Description
Off	No link
Blinking Yellow	Data activity
On	Link

Speed LED	
Status	Description
Off	10Mbps connection or no link
Orange	100Mbps connection
Green	1Gbps connection


## Front RJ45 (1GbE) LAN Port



Activity/Link LED	
Status	Description
Off	No link
Blinking Yellow	Data activity
On	Link

Speed LED	
Status	Description
Off	10Mbps connection or no link
Orange	100Mbps connection
Green	1Gbps connection

## Rear RJ45 (1GbE) LAN Port




Activity/Link LED	
Status	Description
Off	No link
Blinking Yellow	Data activity
On	Link

Speed LED	
Status	Description
Off	10Mbps connection or no link
Green	100Mbps connection
Orange	1Gbps connection


## 2.6 LED

### PSU LED



Status	Description
Green	Normal work; output ON and OK
Blinking Green at 0.5Hz	AC Present Only 12VSB on (PS off) or PSU in Smart Redundant state
Amber	Module fault/protection in operating mode (failure, OCP, OVP, Fan Fail, OTP, UVP) AC cord unplugged
Blinking Amber at 0.5Hz	Warning (high temp, high power, high current, slow fan)

## Rear Fan LED



Status	Description
Off	Normal or no power
Red	Abnormal

## Drive Tray LED



No.	Description
1	Drive tray status LED
2	Drive tray activity LED

## LED Definitions

Status (No. 1)	Activity (No. 2)	Description
Off	Off	Drive not present
Blue	Green	Drive present but not active
Blue	Blinking Green at 4Hz	Drive present and active
Blinking Blue at 4Hz*	Green	Locate
Red*	Green	Fail
Blinking Red at 1Hz*	Blinking Green at 4Hz	Rebuild

\*Work in RAID only

## Chapter 3 Hardware Installation and Maintenance

This chapter helps user to assemble the chassis and install components.

### Before You Begin

Before working with the server, pay close attention to the “Important Safety Instructions” at the beginning of this manual.



1. Ensure the motherboard battery is installed before unplugging the power cord or installing/removing the motherboard.
2. Before installing or removing any component, ensure that the power supply is off or the power cord is detached from the power supply. Failure to do so may cause severe damage to the motherboard, peripherals, and/or components.

#### 1. Make sure the server is powered off.

Power down the server if it is still running.

- (1) Press the Power button to power off the server from full-power mode to standby-power (sleep) mode. The Power LED at the front turns from solid green to blinking green.
- (2) Disconnect the power cord first from the AC outlet and then from the server. The power LED turns off.



*The server is not completely powered down when pressing the Power button on the front panel. The Power button lets the server toggle between Power On and Standby (Sleep) modes. Some internal circuitry remain active in the Standby mode. To remove all power from the system completely, be sure to disconnect the power cord from the server.*

2. Ensure having a clean and stable working environment. Avoid dust and dirt because contaminants may cause malfunctions.
3. Ground properly before touching any system component. A discharge of static electricity may damage components. Wear a grounded wrist strap if available.



1. Some components are already pre-installed. Simply properly connect the relevant cables before or after installation.
2. Refer to the server motherboard user manual for instructions on how to install server motherboard components.


## 3.1 Server Top cover

### Removing the Server Front Top Cover




1. Before removing the top covers, power off the server and unplug the power cord.
2. The system must be operated with the chassis top covers installed to ensure proper cooling.
3. Front top cover and rear top cover can be removed and installed separately.

1. Loosen the screw on the locking tab and press the button to unlock the front top cover.
2. Push the front top cover toward the FRONT of the chassis to release it from the locked position. Lift up and remove the cover.




## Installing the Server Front Top Cover

1. Lower the front top cover on the chassis, making sure the side latches align with the cutouts. Slide the cover toward the REAR of the chassis.
2. Press down the locking tab and tighten the screw to secure the cover.




## Removing the Server Rear Top Cover

1. Hand-release the thumbscrews on the rear side of the chassis.
2. Push the rear top cover toward the REAR of the chassis to release it from the locked position. Lift up and remove the cover.



## Installing the Server Rear Top Cover


1. Lower the rear top cover on the chassis, making sure the side latches align with the cutouts. Slide the cover toward the FRONT of the chassis.
2. Hand-tighten the thumbscrews on the rear side of the chassis.




## 3.2 Hard Drive

### Removing Hard Drive Tray from the Chassis

1. Press the locking lever latch.
2. Open the lever.




3. Pull the drive tray out.



## Installing 2.5" Hard Drive

1. Place the hard drive into the tray with printed circuit board side facing down.
2. Use the bumps on both sides of tray to secure the hard drive.
3. Slide the tray into the hard drive bay.
4. Push in the locking lever to lock the tray in place.



### 3.3 Power Supply

The 6U8X-EGS2 system can accommodate eight power supplies in the bay at the rear of the chassis. Each unit provides up to 3000W of power. Four power supplies are required for full load operation, with the other four power supplies purely as redundant, load-sharing backup. Four power supplies can be removed without affecting system operation.

#### Removing the Power Supply Unit




1. Before replacing the power supply, power off the server, unplug the power cord, and disconnect all wiring from the power supply.
2. The redundant system does not require powering down the server.

1. Hold onto the power supply handle while pressing the locking lever towards the power supply handle.


*Note: The illustration is for references only. The actual PSU type may be slightly different by models.*

2. Pull out the power supply from the chassis.



## Installing the Power Supply Unit


1. Align the power supply unit with the power supply bay.
2. Carefully slide the PSU all the way into the power supply bay until it clicks into place.



## 3.4 System Fan


### Replacing the Top Fan

1. Hand-release the thumbscrew on the side of the fan bar.
2. Lift up the fan bar.
3. Remove the failed fan.
4. Align the mounting holes on the replacement fan with the fan mounts on the fan bar.  
Gently place the fan onto the mounts. Make sure the fan is well seated.
5. Place the fan bar into the chassis.
6. Hand-tighten the thumbscrew to secure the fan bar in place.



## Replacing the Rear Fan

1. Hold onto the fan handle while pressing the locking lever towards the fan handle.
2. Pull out the fan from the chassis.
3. Gently place the replacement fan into the bay.
4. Make sure the fan is well seated.



## 3.5 Add-in Card




1. Before installing the add-in card, power off the server and unplug the power cord.
2. Left bracket and right bracket can be removed independently.


### Installing the Add-in Card

#### FHHL PCIe5.0 x16 (left)


1. Hand-release 3 thumbscrews of left bracket and 1 thumbscrew of right bracket.
2. Lift up the left bracket.




3. Remove the screw securing the blanking plate on the bracket.
4. Slide the blanking plate out sideways.



5. Install the add-in card to the bracket.
6. Secure the add-in card to the bracket with the screw.




7. Align the add-in card assembly with the opening of the chassis and put it in place.
8. Hand-tighten 4 thumbscrews to secure the assembly to the chassis.




### FHHL PCIe5.0 x16 (right)


1. Hand-release 4 thumbscrews securing the right bracket on the chassis.
2. Lift up the bracket.




3. Remove the screw securing the blanking plate on the bracket.
4. Slide the blanking plate out sideways.



5. Install the add-in card to the bracket.
6. Secure the add-in card to the bracket with the screw.




7. Align the add-in card assembly with the opening of the chassis and put it in place.
8. Hand-tighten 4 thumbscrews to secure the assembly to the chassis.




## HHHL PCIe5.0 x16


1. Hand-release the thumbscrew securing the riser-card bracket on the chassis.
2. Pull the latch down.
3. Pull to remove the riser-card bracket from the chassis.




4. Remove the screw securing the blanking plate on the bracket.
5. Slide the blanking plate out sideways.



6. Slot the add-in card to the riser-card board.
7. Secure the add-in card to the bracket with the screw.




8. Align the riser-card assembly with the opening of the chassis and slide it in place.
9. Lift the latch up to lock the add-in card with bracket.
10. Hand-tighten the thumbscrew to secure the assembly to the chassis.



## 3.6 GPU Tray


### Opening the GPU Tray

1. Hand-release the thumbscrews securing the GPU tray to the chassis.
2. Pull the latches down gently.
3. Pull to remove the GPU tray from the chassis.



# Chapter 4 Server Motherboard (SP2C741D32G-2L+)

## 4.1 Layout



No.	Description
1	PSU SMBus Header (PSU_SMB1)
2	System Fan Connector (FAN1)
3	ATX 12V Power Connector (ATX12V4)
4	Micro-Fit Power Connector (ATX4PIN1)
5	ATX 12V Power Connector (ATX12V5)
6	System Fan Connector (FAN2)
7	ATX 12V Power Connector (ATX12V6)
8	System Fan Connector (FAN3)
9	Mini Cool Edge IO Connector (MCIO20)
10	Backplane PCI Express Hot-Plug Connector (CPU1_HSBP1)
11	Mini Cool Edge IO Connector (MCIO19)
12	Mini Cool Edge IO Connector (MCIO18)
13	Mini Cool Edge IO Connector (MCIO17)
14	4 x 288-pin DDR5 DIMM Slots (DDR5_M1, DDR5_N1, DDR5_O1, DDR5_P1)
15	Mini Cool Edge IO Connector (MCIO21)
16	Mini Cool Edge IO Connector (MCIO16)
17	4 x 288-pin DDR5 DIMM Slots (DDR5_M2, DDR5_N2, DDR5_O2, DDR5_P2)
18	Mini Cool Edge IO Connector (MCIO15)
19	LGA 4677 CPU Socket (CPU1)
20	Mini Cool Edge IO Connector (MCIO14)
21	Mini Cool Edge IO Connector (MCIO13)
22	4 x 288-pin DDR5 DIMM Slots (DDR5_I2, DDR5_J2, DDR5_K2, DDR5_L2)
23	Mini Cool Edge IO Connector (MCIO12)
24	4 x 288-pin DDR5 DIMM Slots (DDR5_I1, DDR5_J1, DDR5_K1, DDR5_L1)
25	Mini Cool Edge IO Connector (MCIO11)
26	Thumbscrew
27	Mini Cool Edge IO Connector (MCIO6)
28	4 x 288-pin DDR5 DIMM Slots (DDR5_E1, DDR5_F1, DDR5_G1, DDR5_H1)
29	Mini Cool Edge IO Connector (MCIO5)
30	4 x 288-pin DDR5 DIMM Slots (DDR5_E2, DDR5_F2, DDR5_G2, DDR5_H2)
31	Mini Cool Edge IO Connector (MCIO4)
32	Mini Cool Edge IO Connector (MCIO3)
33	LGA 4677 CPU Socket (CPU0)
34	Mini Cool Edge IO Connector (MCIO2)

No.	Description
35	4 x 288-pin DDR5 DIMM Slots (DDR5_A2, DDR5_B2, DDR5_C2, DDR5_D2)
36	Mini Cool Edge IO Connector (MCIO1)
37	4 x 288-pin DDR5 DIMM Slots (DDR5_A1, DDR5_B1, DDR5_C1, DDR5_D1)
38	Mini Cool Edge IO Connector (MCIO8)
39	Mini Cool Edge IO Connector (MCIO7)
40	Backplane PCI Express Hot-Plug Connector (CPU0_HSBP1)
41	ATX 12V Power Connector (ATX12V3)
42	System Fan Connector (FAN4)
43	ATX 12V Power Connector (ATX12V2)
44	Mini Cool Edge IO Connector (MCIO22)
45	ATX 12V Power Connector (ATX12V1)
46	HDD Backplane Power Connector (BP_PWR1)
47	System Panel Header (PANEL1)
48	USB 3.2 Gen1 Header (USB3_5_6)
49	Non Maskable Interrupt Button (NMI_BTN1)
50	Auxiliary Panel Header (AUX_PANEL1)
51	Intelligent Platform Management Bus Header (IPMB1)
52	System Fan Connector (FAN6)
53	Flash Security Jumper (FLASH_SEC_OVERRIDE1)
54	ME Recovery Jumper (ME_RECOVERY1)
55	System Fan Connector (FAN5)
56	BIOS Swap Override Jumper (BIOS_SWAP_OVERRIDE1)
57	Password Reset Jumper (PASSWORD_CLEAR1)
58	SATA SGPIO Connector (SATA_SGPIO1)
59	Virtual RAID On CPU Header (RAID_1)
60	IPMI LAN LED Header (IPMI_LED1)
61	Speaker Header (SPEAKER1)
62	Liquid Crystal Module Header (LCM1)
63	Rear Panel LAN LED (RL_LED1)
64	MCIO22 PCIe/SATA Selection Jumper (MCIO22_3)
65	SPI TPM Header (TPM_BIOS_PH1)
66	MCIO22 PCIe/SATA Selection Jumper(MCIO22_2)
67	Clear CMOS Pad (CLRMOS1)
68	MCIO22 PCIe/SATA Selection Jumper (MCIO22_1)

No.	Description
69	PWM Configuration Header (PWM_CFG1)
70	Mini Cool Edge IO Connector (MCIO10)
71	M.2 Socket (M2_2) (Type 2280/22110)
72	CPU PECE Mode Jumper (PECE1)
73	Mini Cool Edge IO Connector (MCIO9)
74	M.2 Socket (M2_1) (Type 2280/22110)
75	NCSI Mode Jumper (NCSI_SEL1)
76	NCSI Header (NCSI1)
77	Front VGA Header (FRNT_VGA1)
78	COM Port Header (COM1)
79	USB 3.2 Gen1 Header (USB3_7_8)
80	BMC SMBus Header (BMC_SMB3)
81	BMC SMBus Header (BMC_SMB2)
82	BMC SMBus Header (BMC_SMB1)



### 4.3 Installing the CPU and Heatsink (LGA 4677 Socket)




1. Unplug all power cables before installing the CPU.
2. Illustration in this documentation are examples only.


#### Carrier Used

Carrier Type	Xeon® SP XCC	Xeon® SP MCC/LCC
Carrier Code	E1A	E1B
Shim	No	Yes
Carrier Height	16.70mm	17.55mm

#### XCC Carrier




#### MCC Carrier






Unplug all power cables before installing the CPU.


1




2




3




4




5




6




7




8



9



10




## 4.4 Installing the Memory Modules (DIMM)




The DIMM only fits in one correct orientation. It will cause permanent damage to the server motherboard and the DIMM if forcing the DIMM into the slot at incorrect orientation. For more information about DIMM installation, refer to the server motherboard user manual.


1



2



3



## Appendix


### Installing the Server in a Rack

The section describes how to rackmount the server with slide rail assembly.



*The rails installation instructions in this manual are example only, the actual rail assembly procedure may differ slightly.*


The rail assembly consists of outer, middle and inner rail.




*Some slide rails are labeled with either L or R, please identify prior to rail installation. Install the rail labeled with L on the left side of rack, and the rail labeled with R on the right side.*

## Remove the inner rail

1. Pull the inner rail out.
2. Push locking plate to remove the inner rail from the rail assembly.




3. Push tab to slide the middle rail.



### Install inner rail onto the chassis

For safety concern, user can fasten the screw (screw hole A as below picture) on the end of inner member while assembling on the chassis.



Install the inner member onto the chassis by this direction.




### Mount the server in rack

1. Pull out middle rail and confirm if it's locked (Click!).
2. Make sure ball bearing retainer is located at the front of the middle rail.
3. Aim the rear end of inner rail to middle rail, Horizontally insert the chassis to middle and out rail.
4. When chassis is locked, push release tab on both sides and continue sliding the chassis to the rack.
5. Fasten chassis ear screws and secure the rail with shipping screws.



*At least two people are required for chassis installation.*



## Contact Information

Contact ASRock Rack or want to know more about ASRock Rack, you're welcome to visit ASRock Rack's website at <http://www.asrockrack.com>; or contact the dealer for further information. For technical questions, please submit a support request form at <https://event.asrockrack.com/tsd.asp>

### **ASRock Rack Incorporation**

e-mail: [ASRockRack\\_sales@asrockrack.com](mailto:ASRockRack_sales@asrockrack.com)

### **ASRock Rack EUROPE B.V.**

Bijsterhuizen 11-11  
6546 AR Nijmegen  
The Netherlands  
Phone: +31-24-345-44-33

### **ASRock Rack America, Inc.**

4331 Eucalyptus Ave, Chino, CA 91710 U.S.A.  
Phone: +1-909-590-8308  
Fax: +1-909-590-1026